

Step 1. - Remove old Grip.




Step 2. - Remove ALL old tape from shaft of club.



Step 3. - Mark shaft for the length of the tape.




Step 4. - Measure Hand size - see chart at right for MAXIMUM build up.




Hand Size (measure from crease in wrist to tip of longest finger)	Recommended GGA Grip size
less than 6 1/2"	2 extra wraps lower hand
6 1/2" to less than 7"	3 wraps lower hand, 1 wrap upper
7" to less than 7 1/2"	4 wraps lower hand, 2 wraps upper
7 1/2" to less than 8"	5 wraps lower hand, 3 wraps upper
more than 8"	6 wraps lower hand, 4 wraps upper

Step 5. - Build up tape on shaft according to hand size chart. Mark middle of grip for appropriate build up of lower and upper hands.



Step 6. - Put Solvent in Grip and on tape.



Step 7 - Install Grip. **RED** 'G' up for right handed golfer, **WHITE** 'G' up for left handed golfer



Right Hand side red 'G'

Left Hand side white 'G'

Step 8 - Align 'tick' marks on each end of grip and center line with square club face.

